

### ProLaser 3

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlk	230	632	617	
Bonehead	JTG	JTG	JTG	
Th3FactoryFreak	150	231	142	
Mech33	177	133	236	
DJrams80	JTG	224	110	140
PoserShadow	328	273	319	JFG
Obsidian	157	213	162	287
Oyusan	JTG	184	206	163

### LRB

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlk	609	653	664	
Bonehead	95	245	135	
Th3FactoryFreak	138	139	638	
Mech33	281	284	115	
DJrams80	308	280	JTG	JFG
PoserShadow	462	317	377	108
Obsidian	271	324	462	144
Oyusan	154	153	JTG	132 / 272

### Stalker Laser

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlk	N/A	N/A	N/A	N/A
Bonehead	JTG	JTG	128	
Th3FactoryFreak	133	137	JTG	
Mech33	149	118	124	
DJrams80	118	JTG	751 / 110	73
PoserShadow	540 / 159	226	307	107
Obsidian	671 / 268	131	147	116
Oyusan	226	114	99	129 / 509

### Stalker Lidar LR

Member	Passenger HL	COM	Driver HL	Passenger TL
--------	--------------	-----	-----------	--------------

PntBlnk	N/A	N/A	N/A	N/A
Bonehead	JTG	JTG	112	
Th3FactoryFreak	109	119	JTG	
Mech33	123	110	104	
DJrams80	JTG	JTG	JTG	64
PoserShadow	195	JTG	146	75
Obsidian	JTG	JTG	JTG	115
Oyusan	JTG	JTG	JTG	145 / 263

### TruSpeed

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlnk	JTG	208	281	
Bonehead	120	JTG	163	
Th3FactoryFreak	657 / 407	180	682	
Mech33	286	170	JTG	
DJrams80	146	322	JTG	178 / 573
PoserShadow	624 / 243	249	277	165 / 568
Obsidian	257	252	296	JFG
Oyusan	226	232	JTG	JFG

### TruSpeed S

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlnk	N/A	N/A	N/A	N/A
Bonehead	JTG	JTG	JTG	
Th3FactoryFreak	N/A	N/A	N/A	N/A
Mech33	165	163	219 / 143	
DJrams80	JTG	237 / 154	189 / 113	N/A
PoserShadow	332 / 157	228 / 151	592 / 221	N/A
Obsidian	578 / 145	164	120	161 / 311
Oyusan	114	187	112	N/A

### Prolite+

Member	Passenger HL	COM	Driver HL	Passenger TL
PntBlnk	N/A	N/A	N/A	N/A
Bonehead	JTG	JTG	349	
Th3FactoryFreak	154	135	JTG	

Mech33	122	152	JTG	
DJrams80	134	JTG	JTG	JFG
PoserShadow	307 / 140	JTG	JTG	JFG
Obsidian	196	110	65	136
Oyusan	202	190	JTG	137 / 314

Rear Plate

Driver TL

JFG	126
JFG	JFG
JFG	JFG
JFG	137

Rear Plate

Driver TL

119	237
JFG	93
JFG	130 / 495
JFG	150

Rear Plate  
N/A

Driver TL  
N/A

66	68
78	JFG
JFG	116 / 266
356	124 / 439

Rear Plate

Driver TL

N/A	N/A
-----	-----

JFG	63
JFG	70
JFG	93
JFG	109

Rear Plate	Driver TL
------------	-----------

JFG	90 / 277
JFG	98 / 160
JFG	126 / 205
308	106 / 442

Rear Plate	Driver TL
------------	-----------

N/A	N/A
-----	-----

N/A	N/A
-----	-----

68 / 245	69 / 289
111	91
N/A	113 / 200
JFG	160

Rear Plate	Driver TL
------------	-----------

N/A	N/A
-----	-----

JFG	97
82	114
177	109 / 215
JFG	124